

# FabricMaster Heavy Duty™ Self-Neutralizing Upholstery & Fabric Preconditioning Agent



- » **FabricMaster HD** Upholstery Pre-spray is designed for the upholstery cleaning craftsperson. While many cleaners use carpet pre-sprays on upholstery, the craftsperson recognizes the important differences between upholstered fabrics and carpeting, as well as the soils that build up in them.
- » **FabricMaster HD** is a self-neutralizing formula that cleans with the power of alkalinity, but then self-neutralizes as it dries. It is designed for use on synthetic upholstery fabrics. It does all of this with the cleaning power of odorless ammonia, combined with specialized solvents and surfactants.
- » This specialized formula is specifically designed to break down, dissolve, and emulsify the soils and spills most common to upholstery fabrics – body oils, hair treatments, airborne oils, shoe scuffs, spilled food and beverages, crocked colors from clothes, newsprint, and pet hair.
- » **FabricMaster HD** is a low foaming formula that does not leave a sticky residue. A special additive helps the fabric dry faster after cleaning reducing the chances for overwetting based problems.
- » **FabricMaster HD** contains the same stain removing additive that is in our famous **SpotMaster Pro XP** spotting agent, effectively removing many beverage spills without the need for special stain treatments.

*If for any reason you are not thrilled with the performance of **FabricMaster HD** return it to your distributor and we'll get you a product that does.*



## Directions:

1. Vacuum fabric thoroughly before starting cleaning process.
2. Always pre-test all cleaning solutions in an inconspicuous area for colorfastness prior to application.
3. For light to medium soil, mix 1 part **FabricMaster HD** with 4 parts water (32 ounces of solution with 1 gallon of water) into sprayer. For heavy soiling, mix 1 part solution with 1 part water (64 ounces of solution with 64 ounces of water)
4. Apply with hand-held pump up or trigger sprayer in an even, overlapping mist across the entire area of the fabric being cleaned.
5. Allow to dwell for 2-3 minutes. Be careful not to overspray or breathe mist.
6. Agitate with horsehair brush or bonnet mitt.
7. For best results extract area with **CleanMaster RinseOut** utilizing the **HydraMaster DriMaster 2 or 3 Upholstery Cleaning Tool**.
8. For faster drying, especially in humid environments, consider the use of an axial, centrifugal, or downdraft air mover after cleaning.

See the material safety data sheet at [www.cleanmaster.com](http://www.cleanmaster.com) for safety and regulatory information.

Learn more,  
scan here



Available in: 1 Gallon; Case of 4 x 1 Gallon

Part number: 950-230-S, B

11015 47th Ave W, Mukilteo, WA 98275

[www.cleanmaster.com](http://www.cleanmaster.com) • 877.282.2319

**CLEANMaster**  
HydraMaster Cleaning Solutions

